


EUROFLOOD

Installation Instructions

EUROFLOOD SL SMALL



V0



i

Power (W)	Ta°C
≤50	-40°...+50°
≤135	-40°...+40°

kg = 8,2

i

235°
Angle Step 5°

1

Or

70-80

145-155

2 pcs. M12

i

L=30mm
L=8mm

ELECTRONIC				DALI DIM			
N	⊖	L		N	⊖	L	1 2
N	⊖	L		N	⊖	L	D1/+ D2/-

! *The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.