


# EUROFLOOD

## Installation Instructions

### EUROFLOOD SL MEDIUM



v0



**i**

Power(W)	Ta°C
≤152	-40°...+50°
≤215	-40°...+45°
≤250	-40°...+40°

**kg** = 13

**i**

235°  
Angle Step 5°

**1**

2 pcs. M12

**i**

ELECTRONIC				DALI DIM			
N	⊖	L		N	⊖	L	1 2
N	⊖	L		N	⊖	L	D1/+ D2/-

**!** \*The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.